

BLUESTONE INSTALLATION TIPS **(MOISTURE SENSITIVE PRODUCTS)**

Due to the characteristics and porosity of some natural stone products, and the availability of many different adhesives, we strongly recommend buttering the full rear face of each tile with adhesive. This will ensure the best installation results. To minimise the amount of adhesive used, screed the substrate evenly and make use of a smaller notched trowel. Ensure that all tiles are sealed prior to installation. It is recommended to use a fast curing adhesive. Following these instructions will minimise the possibilities of any substances emigrating to the surface of the stone.

Please contact your local adhesive supplier for the most suitable product before installation.